



26900 Jefferson Avenue, Murrieta, CA 92562

**#01017005 – “93-02 Camaro_Firebird” Tonneau Cover
Installation Instructions**

**Phone: 951.894.7883,
FAX 951.894.7920**

- 1. Using the hardware provided, bolt the two halves of the tonneau cover together.**
- 2. Retract the convertible top to the fully lowered (down) position. Insert the rear flange (Fig. #1) on the tonneau covers between the top and the upper body.**
- 3. Lower the front of the tonneau cover and allow the sides to fit down along the side trim pieces. (Fig. #2)**
- 4. Install the shoulder strap portion of the seatbelts through the slots on the tonneau cover on both the driver’s side and passenger side.**
- 5. IMPORTANT !! Make sure the foam pieces provided are in the proper location as to provide**

