



PRODUCT INSTALLATION INSTRUCTIONS

**If you require assistance beyond the scope of these instructions
call tech assistance at 951-894-7883 or go online www.rksport.com**

Sunfire Spoiler

Fitment: 1995 > Present Sunfire Coupe 2dr

Tools Required:

Electric drill
assorted drill bits
tape measure
Phillips screw driver

Instructions:

Locate the spoiler on the rear deck lid so that the mounts conform to the curvature of the rear deck lid. Mark this exact location with masking tape. Next insert the "T" straps into the bolt holes in the wing pedestals. Place the wing back on the car in the proper location and tape the "T" straps to the surface of the car. Remove the wing leaving the "T" straps in place to reveal where the holes for the spoiler are required. Use the pilot holes in the "T" strap to drill through the trunk lid. You will need to oversize the hole in the under side of the trunk lid to accommodate the larger size of the bolt head. We highly recommend using a sealant such as silicone to seal all openings drilled through the trunk lid.

Painting Instructions:

Before any installation begins it is important to dry fit all of the parts. Spray the surface with a cleaner to remove any dirt or foreign material. Apply a very light black coat to the gel coat to help with sanding. This will help identify high or low spots that would otherwise be difficult to see. Using 180 grit paper, block sand to remove any imperfections, making sure you leave as much gel coat as possible. The gel coat seals the fiberglass, and prevents the fiber glass from bleeding through and soaking up paint. Whenever sand to establish smoothness use a flat block, to prevent irregularities. Wipe the surface thoroughly after sanding to remove any dust. After all of this is complete the first coat of primer may be applied.