



PRODUCT INSTALLATION INSTRUCTIONS: RK Sport Part #24012010, Dodge Charger & Dodge Charger “Heritage” Rear Spoiler

If you require assistance beyond the scope of these instructions, please call our Technical Assistance Team at: 951.894.7883 and ask for installation assistance.

Packing List

Quantity	Description
(1)	Spoiler (Center Piece)
(2)	Spoiler (End “Ear” Pieces)
(2)	1/4” X 1” Panhead Bolts, Washers & Nuts

This Spoiler is designed for use on the 06’ & Up Dodge Charger & 06” & Up Dodge “Heritage” Charger. Please read all the instructions carefully before installing this product.

1. Always pre fit parts to vehicle prior to painting.
2. Mount center section of the spoiler onto the rear deck lid first using the provided “T-Straps”.
NOTE: The center “bolt” hole is an “air hole” vent.
3. Put T-straps in bolt holes of center section of the wing and place on vehicle. Secure T-straps to vehicle using masking tape so that they will stay on the vehicle as you remove the part from the vehicle.
4. Using a 1/8” drill bit drill through “pilot hole” of the T-strap.
5. Remove T-strap and drill 1/4” holes.
6. Prep & clean the surface well. It is recommended to clean it at least (5)X’s ensuring a clean surface.
7. Mount wing to the trunk lid using the 1/4” Panhead bolts supplied in your kit.
8. To mount the Left & Right ears use the same preparation methods as described above and apply utilizing the “Double-Sided” adhesive tape supplied.

Hardware:

T-straps

1/4x20x1/2 Panhead bolts

