



Installation instructions for RKSport Part #'s 26012004-26012005 Solstice Rear Exhaust Filler

- 1. Jack rear of vehicle and support with jack stands.**
- 2. Remove rear wheels.**
- 3. Remove rear bumper from vehicle. (You will need to remove rear tail lights to expose all hardware.)**
- 4. Remove lower filler from bumper.**
- 5. Install Carbon Fiber filler to stock bumper by inserting metal tabs into the bumper slots and bending the metal tabs to secure it to the bumper.**
- 6. Using a 1/4" drill bit drill 2 holes on the bottom edge of the carbon panel and through the bumper. Then place the plastic fastener into the holes.**
- 7. Replace rear bumper to car using all OE hardware.**