



Product Installation Instructions

If you require assistance beyond the scope of these instructions, please call our Tech Assistance Team at 951-894-7883 or go on-line at www.rksport.com

INSTALLATION INSTRUCTIONS FOR THE RKSPORT SATURN SKY GROUND EFFECTS KIT

TOOLS REQUIRED

- 3/8" Drill Motor
- 1/8" Drill Bit & a Standard Length Phillips Head Screw Driver
- Acetone or similar Alcohol based cleaning solution for surface prep

GENERAL NOTES

Remove the parts from the carton and unfold them. The front valance has a memory. When it is placed in the sun or heated with a hair dryer, they will return to shape.

Important: Pre-fit parts to the car & do not remove the double-sided tape or red backing until final installation. If drying painted parts in oven, carefully support each piece evenly.

FRONT AIR DAM

Fit front Air Dam in place by first attaching the ears that wrap around into the wheel well by using a spring clamp or duct tape. Next, pull up center into proper position and make sure that it is centered. Tape securely into place with masking tape. Next, pull up each corner until you are satisfied with your fit & then drill your 1/8" inch mounting holes. After the holes have been drilled, remove the part and clean out all shavings between the car and fascia and the part. Clean attachment areas well with Acetone or similar Alcohol based solvent and use the supplied adhesive promoter pen on surface where the tape will stick. Finally, install the part.

SIDE SKIRTS

Pre-fit to car, tape into place with the door closed. Make sure that the skirt is securely pressed into position. Drill 1/8" inch holes for the self tapping screws. Clean attachment areas well with Acetone or similar Alcohol based solvent and use the supplied adhesive promoter pen on surface where the tape will stick. Finally, install the part.