



Painting Instructions:

Before any installation begins it is important to dry fit all of the parts. Spray the surface with a cleaner to remove any dirt or foreign material. Apply a very light black coat to the gel coat to help with sanding. This will help identify high or low spots that would otherwise be difficult to see. Using 180 grit paper, block sand to remove any imperfections, making sure you leave as much gel coat as possible. The gel coat seals the fiberglass, and prevents the fiber glass from bleeding through and soaking up paint. Whenever sand to establish smoothness use a flat block, to prevent irregularities. Wipe the surface thoroughly after sanding to remove any dust. After all of this is complete the first coat of primer may be applied.



Painting Instructions:

Before any installation begins it is important to dry fit all of the parts. Spray the surface with a cleaner to remove any dirt or foreign material. Apply a very light black coat to the gel coat to help with sanding. This will help identify high or low spots that would otherwise be difficult to see. Using 180 grit paper, block sand to remove any imperfections, making sure you leave as much gel coat as possible. The gel coat seals the fiberglass, and prevents the fiber glass from bleeding through and soaking up paint. Whenever sand to establish smoothness use a flat block, to prevent irregularities. Wipe the surface thoroughly after sanding to remove any dust. After all of this is complete the first coat of primer may be applied.



Painting Instructions:

Before any installation begins it is important to dry fit all of the parts. Spray the surface with a cleaner to remove any dirt or foreign material. Apply a very light black coat to the gel coat to help with sanding. This will help identify high or low spots that would otherwise be difficult to see. Using 180 grit paper, block sand to remove any imperfections, making sure you leave as much gel coat as possible. The gel coat seals the fiberglass, and prevents the fiber glass from bleeding through and soaking up paint. Whenever sand to establish smoothness use a flat block, to prevent irregularities. Wipe the surface thoroughly after sanding to remove any dust. After all of this is complete the first coat of primer may be applied.