PRODUCT INSTALLATION INSTRUCTIONS

If you require assistance beyond the scope of these instructions call tech assistance at 760-433-1663 or go online www.rksport.com

INSTALLATION TIPS FOR MONTE CARLO RK-Z34 GROUND EFFECTS PACKAGE

First remove parts from the box and allow the front and rear fasciae to straighten by either placing under a heat lamp, hair dryer, or placing in the sun. (The urethane has a good memory.) Pre-fitting to the car prior to painting is suggested.

FRONT AND REAR FASCIA

Attachment is a combination of self-tapping screws and double sided tape. Use (2) two screws on each flange that wraps into the wheel well. On front fascia, we suggest placing (2) self-tapping screws in fascia from under car in front of radiator, screwing down through new fascia into existing fascia. This places the screws so that they are hidden in the rear. Rear fascia requires (3) three self-tapping screws to be installed under center rear where the fascias make contact.

SIDE SKIRTS

The side skirts require (2) self-tapping screws in each flange in the wheel well. (3) Three self-tapping screws are required along the door sill (one in the center and one at each extreme end.)

DOOR PANELS

Door panels replace your stock panels. Panel should be flush with rear edge of door. When mounting it is extremely important that surface is cleaned thoroughly with a lacquer thinner or reducer a minimum of four times.

251 Airport Road Oceanside,CA 92054 Tel 1-(760)-433-1663 Fax 1-(760)-433-1477
www.rksport.com

PRODUCT INSTALLATION INSTRUCTIONS

If you require assistance beyond the scope of these instructions call tech assistance at 760-722-1374 or go online www.rksport.com

ATTENTION

THE FOLLOWING CONTAINS IMPORTANT INFORMATION REGARDING PAINTING OF THE URETHANE PIECES. IT IS IMPERATIVE THAT THESE STEPS BE FOLLOWED IN ORDER TO AVOID ANY PROBLEMS WITH THE PAINT. IF THESE INSTRUCTIONS ARE NOT FOLLOWED, YOU MAY EXPERIENCE PEELING, CHIPPING, AND BUBBLING OF THE PAINT.

PAINTING INSTRUCTIONS

1. **All painted surfaces must be sanded with 150 grit paper. This is very important, as the primer needs a rough surface for adhesion.**
2. **Clean with wax and grease remover.**
3. **Prime with urethane primer with a flex additive.**
4. **Putty any pinholes.**
5. **Re-prime, if necessary.**
6. **Pre-fit parts to vehicle.**
7. **Hand sand with 320 grit sand paper.**
8. **Clean with wax and grease remover.**
9. **Paint-add flex additive to the paint.**

251 Airport Road Oceanside,CA 92054 Tel 1-(760)-433-1663 Fax 1-(760)-433-1477
www.rksport.com